

# NIKON SUPER COOLSCAN 8000

## HOW TO SCAN 35 MM SLIDES

1. Load the slides into the tray horizontally with the white (front) facing up.
2. Insert the slide tray into the scanner following the directive arrows on the slide tray. Push it gently into the opening until you feel the scanner pull the slide tray in.
3. Open **Adobe Photoshop**
4. To open the scanning program go to **file / import / Nikon Scan 4.0**. The software will open when the green light on the scanner stops blinking (the blinking light indicates that the scanner is busy)
5. Once the scanning program has opened, roll the mouse over the toolbar in the window labeled **Nikon Super CoolScan 8000 ED 1.11**. When the mouse is rolled over the right-hand side of the tool bar a small tray with four squares should slide out of the tool bar. Click on this tray to manage and view thumbnails of the images.
6. When the tray has popped out, click on the square labeled **1** (the first slide) then hold down the shift key and click on the square labeled **5** or whatever number indicates the last slide in the tray.
7. Select **Preview** (this may take a few minutes).
8. When the scanner finishes select the first slide.
9. **Crop** the image by going to the **Tool Palette** window, to the section labeled **Crop** and find the tiny arrow located directly across from where it says **Crop**. Click on this arrow to pull down a menu and from this menu select **Standard**. Double check that the **Resolution** is set at **3,000 pixels per inch**.
10. If the slide image is **color** slide enable **Digital Ice** under its menu in the **Tool Palette** window.
11. If the slide image is **black and white** do not select **Digital Ice**.
12. Repeat the above for each desired slide.
13. Once you've adjusted settings for each image, click on the little square labeled **1** again, hold down the shift key, and click on square **5**.
14. Click scan to **Scan** all selected images (again, it will take some time).
15. The slide drawer will eject when the scanning process is finished. If it doesn't, press the eject button on the scanner.
16. Proceed to **HOW TO USE PHOTOSHOP instructions**.